



DEXTER[®]
LAUNDRY



WC-Series Vended Washers
USB PROGRAMMING GUIDE

DexterLive

The new DexterLive controls were created for you to be able to interface easier with your equipment and create variable pricing cycles to increase your profitability in the same floor space.

First, log into DexterLive, create your location and equipment list and then create your cycle and pricing information by the particular type of washer and dryer at the location. Once the information is saved, download the "AllUser.xml" file to a USB device which will be used to program the machines from the USB port.

Keep it simple or use the marketing features such as temperature pricing, plus cycle or an additional final rinse that the customer can select for a value added wash. Utilize time of day pricing to help move people from heavy use periods to special value times of day or days of the week.

Through the easy to use USB programming so you can download all special pricing and cycles from DexterLive to set up your store quickly and easily.



Accessible

Available anytime, anywhere, on any internet capable device. Once you have set up your free account all of your custom settings and store information are saved making it quick and easy to make future changes.

Simple


View and customize equipment settings to fit your business model. Download your unique user file and quickly transfer it to your equipment via USB.

Profitable

Create exciting promotions to attract new customers. Offer extra prewash, plus cycles, Extra rinse and temperature pricing to drive more revenue in your store.

First Time Creating an Account at Dexter Live


- 1) Log into DexterLive
At the bottom, select "Create your DexterLive account."



The screenshot shows the DexterLive login interface. At the top is the DexterLive logo. Below it, the text "Log in to DexterLive:" is displayed. There are two input fields for "Email" and "Password". A "Remember Me" checkbox is located below the password field. A blue "LOGIN" button is centered below the inputs. Below the button is a link that says "I forgot my password." At the bottom of the form area, there is a link that says "Need to sign up? Create your DexterLive account." In the bottom left corner, there are small links for "Privacy Policy" and "Terms of Service".

DexterLive gives an owner the ability to manage multiple locations.

- 2) At the "Create a DexterLive Account" screen.
 - A. First time users must create an account.



The screenshot shows the "Create a DexterLive Account" form. It features the DexterLive logo at the top. The title "Create a DexterLive Account" is centered. The form includes input fields for "Name", "Company Name", "Phone Number", and "Email". Below these are fields for "Password" and "Confirm". A checkbox is present with the text "I have read and accepted the Terms of Service". A blue "CREATE MY ACCOUNT" button is centered at the bottom of the form area. Below the button is a link that says "Already have an account? LOGIN". In the bottom left corner, there are small links for "Privacy Policy" and "Terms of Service".

An account must be created to use the DexterLive features.

- B. Fill in the required fields and click on "Create My Account".

The screenshot shows the "Create a DexterLive Account" form. At the top is the Dexter Laundry logo. Below it, the title "Create a DexterLive Account." is followed by several input fields: "Name" (with placeholder "Your Name"), "Company Name" (with placeholder "ABC Laundry"), "Phone Number" (with placeholder "xxx xxx xxxx"), and "Email" (with placeholder "YourEmail@ServiceProvider.com"). There are also fields for "Password" and "Confirm" (both with placeholder "*****"). A checkbox labeled "I have read and accepted the Terms of Service" is checked. At the bottom is a blue "CREATE MY ACCOUNT" button. In the bottom left corner, there is a link for "Privacy Policy | Terms of Service" and the text "DexterLive™ Dexter Laundry, Inc."


When creating a new user account make sure to fill in all fields marked with asterisks and check the "Terms of Service" box.

- C. After selecting to "Create My Account", you will see the log in screen advising you to go to your e-mail and activate your account.

The screenshot shows the "Log in to DexterLive" screen. It features the Dexter Laundry logo and the title "Log in to DexterLive:". Below the title are input fields for "Email" and "Password". There is a "Remember Me" checkbox and a blue "LOG IN" button. Below the button is a link that says "Forgot my password!". At the bottom, there is a blue bar with the text "Need to sign up? Create your DexterLive account." In the top right corner, a green message box states: "A message with a confirmation link has been sent to your email address. Please open the link to activate your account." In the bottom left corner, there is a link for "Privacy Policy | Terms of Service" and the text "DexterLive™ Dexter Laundry, Inc."


After creating your account you will need to use the e-mail link to gain first access. The account will not be active until you confirm your account.

- 3) Open the e-mail sent from Dexterlive and select “CONFIRM MY ACCOUNT”



Selecting the “Confirm My Account” hyperlink will take you back to the DexterLive log in page.


- 4) At the “Log into DexterLive” screen, enter your e-mail/user name and password to access DexterLive.



Welcome to DexterLive. Proceed to the step to create your location information.


Programming

- 5) Configure your settings with DexterLive.com
 - A. Add or select a location to program.



DexterLive gives an owner the ability to manage multiple locations and machines.

- B. On the left side of the screen, select the "Programming" tab.



Follow instructions in the programming tab.

C. Edit the "General Settings" (Equipment Tab)

Locations

Easy wash laundry
400 main street

Equipment

Promotions

Users

Programming

General Settings - All Machine Types

Washers and Dryers

Machine Display Language: English

Display Decimal Point: On

Sounds: On

Password: 0000

Time Shift: +0 hours : 0 minutes

Washers Only

Drive Table: Current

Dryers Only

Display Temperature Scale: °F

Display Time: Minutes only displayed

Central Pay: Off

Cancel Save

Adjust setting and offset time to match your location. (Time is set for Central Standard Time)

D. Next select the "+Add Equipment" (Equipment Tab), located in the upper right hand corner.

Locations

Easy wash laundry
400 main street

Equipment

Promotions

Users

Programming

EQUIPMENT

General Settings + Add Equipment

T-350 Express Washer
6 units at this location

Add Machine

My Machine Name: D1

Serial Number: D2.14076.006

Machine Type: T.30X2 Stack Dryer

DexterLive ID: [Empty]

SAVE & CONTINUE

Done adding machines

Name of the machine. (Example: Dryer 1)
Enter serial number and machine type then select "Save and Continue."

- E. When all of the equipment has been added, select “Edit” on the machine type you wish to modify, and then select “Pricing”. (Equipment Tab and Machine Settings Tab)

T-350 EXPRESS WASHER

Pricing Cycles

Pricing	Base Vend Price	3.50
Adders	Warm Temp Adder	0.25
	Hot Temp Adder	0.50
	Pre-Wash Adder	FREE
	Extend Wash Adder	0.25
	Extra Rinse Adder	FREE
Promotional Pricing	Base Vend Price (B)	3.00
	Base Vend Price (C)	3.50
Coin Values	Left Coin Value	0.25
	Right Coin Value	1.00

Cancel Save for all T-350s

Program the price of the machine and the extra pricing adders.

- F. Make the cycle changes by selecting the “Cycles” tab.

T-350 EXPRESS WASHER


Pricing Cycles

Cycle	Time	Temp	Spin
Pre-Wash	Off	Cold	Off
Wash	9 min	Warm	Off
Extended Wash	1 min		
Rinse	4 min	Cold	1 min
Final Rinse	5 min	Cold	6 min
Extra Rinse	Off	Cold	Off
Extract Speed	Final Spin Speed	200G	
Options	Delay Fill	Off	
	Delay Spin	Off	

Cancel Save for all T-350s


Adjust cycle programming set the length of time and extracts speed as needed.

- G. You can now create and edit optional store promotions from the “Promotions Tab”.



Select “Save Promotion” once your changes have been made.

- 6) Create and Download Programming File.
 A. Once all preferred prices, cycles and promotions have been modified and saved, select **“DOWNLOAD PROGRAMMING FILE”**.




-
- B. Based on your internet browser the file needs to be saved as "AllUser.xml". Depending on your Internet browser you may need to retrieve the file from your "Downloads" folder.

Note: Machine programming will not occur using a different file name than "AllUser.xml". Any extra extension names will require the file to be renamed back to "AllUser.xml" for the machine to recognize the file.

7) Save the Programming File to a USB Drive

- A. Move or Copy the "AllUser.xml" file from your computer onto a USB drive.
- B. Based on your computer and internet browser, this file may be found in your "Downloads" folder.


Note: The "AllUser.xml" file size is small, nearly any capacity USB drive will do.



8) Program Your Machines Using the USB Drive

- A. Insert the USB drive containing the "AllUser.xml" file into the Dexter machines you wish to program. The control will scroll "....." while identifying the program on the USB. Once identified, the display will scroll "INSTALL USER FILE FROM USB". At this prompt press the green start button on the front panel.

-
- B. The machine will scroll "TO INSTALL – PRESS START". At this prompt, press the green "Start" again.



- C. Once the program is uploaded successfully the control will scroll "DONE REMOVE USB". The USB drive can be safely removed at this point.

Note: All Dexter equipment (washers and dryers) featuring DexterLive controls can be programmed using this file once the equipment has been configured.