



DEXTER.
LAUNDRY

CYCLE OPTIONS

OMIT ALL FLUSHES

1. Remove the clear in-line splice from the end of the orange/white wire.
(This wire will be laying loose next to the terminal strip)
2. Connect the orange/white wire to terminal #2 on the terminal strip.

OMIT HOT RINSES ON RINSE #1 & #2

1. Remove brown/red wire from coil of R5 relay and insulate wire.

ADD HOT RINSES ON RINSE #1 & #2 ON TEMPERATURE PUSH BUTTON POSITION #3

1. Remove black jumper from back of temperature switch that connects push button #3 N.O. (82) to push button #4 N.O. (81)
2. Move white/brown wire on back of temperature switch to push button #4 N.O. (81).

ADD COLD RINSES ON RINSE #3, #4 & #5 ON TEMPERATURE PUSH BUTTON POSITION #3

1. Move brown/orange wire from push button #3 Common (A2) to push button #3 N.C. (C2).