

Section 8

Maintenance

Daily

1. Clean the top and the cabinet to remove residue from undissolved soap.
2. Clean the soap dispenser and soap lid.
3. Check the drain for leaking and proper draining also inspect for any other water drops around machine as water drops can lead to Floods.
4. Check the loading door for leaks.
5. Clean the door seal of all foreign material.
6. Leave the loading door open to aerate the washer when not in use.
7. Inspect and reinstall all panels and guards.

Quarterly

- Make sure the power is disconnected before making the following checks.
1. Check the drive belt for wear and proper tension.
 2. Clean lint and other foreign material from around drive motor.
 3. Check all water hose connections for leaks.(inside machine with top off)
 4. Wipe and clean the inside of the washer and check all electrical components for moisture and dust.
 5. Remove and clean water inlet hose filters. Replace if necessary.
 6. After any service always replace all panels before reconnecting electrical power.
 7. Inspect and reinstall all panels and guards.

Yearly

1. Inspect water level pressure switch line. (blow down from switch to drain)