

SECTION 8

PREVENTATIVE MAINTENANCE INSTRUCTIONS

WEEKLY

1. Clean lint screen and compartment. Use soft brush if necessary.
Failure to do so will slow drying and increase gas usage and temperatures throughout the dryer.
2. Check lint screen for tears. Replace if necessary.

MONTHLY

1. Check the end bells of the drive motor for lint accumulation and clean if necessary.
2. Check the lint screen compartment for lint accumulation and clean if necessary.
3. Check for lint and dirt accumulation on top of the dryer and all area above, and around the burners and burner housing. Clean where necessary. Failure to keep this portion of the dryer clean can lead to a build-up of lint creating a fire hazard.
4. Place a few drops of light oil on top and bottom pivots of the clothes door hinge.
5. Grease bearings and shaft of intermediate drive pulley.

QUARTERLY

1. Check belts for looseness, wear or fraying.
2. Inspect gasket of door glass for excessive wear.
3. Check tightness of all fasteners holding parts to rear support channel.
4. Check tightness of tumbler shaft retaining nut.
5. Check for lint accumulation in primary air ports in burners and clean if necessary.
6. Grease pivot pins and tension arms where in contact with each other.

SEMI-ANNUALLY

1. Check and clean main burners if necessary.
2. Check all orifices and examine for dirt and hole obstruction.
3. Check the interior of the dryer for lint accumulation.

ANNUALLY

1. Check intermediate pulley bearings for wear.
2. Check and remove any lint accumulation from exhaust system.

