

WASHER PREVENTIVE MAINTENANCE (PM) REQUIREMENTS

MAKE SURE ALL POWER IS DISCONNECTED BEFORE MAKING CHECKS INSIDE MACHINE.

DAILY

1. Clean the cabinet top around soap dispenser.
2. Clean the soap dispenser and soap lid and check that all dispenser mounting screws are in place and tight.
3. Check the drain for leaking and proper draining.
4. Check the water connections for leaks.
5. Check door seal for foreign material.
6. Leave the loading door open to aerate the washer when not in use.

QUARTERLY

1. Check the drive belt for wear and proper tension.
2. Clean lint and other foreign material from around drive motor.
3. Remove water inlet hose filter screens and clean or replace as necessary .
4. Check all electrical components for moisture and wipe away any foreign debris.

ANNUALLY

1. Clean and remove lint and foreign debris from outside cover of VFD with a dry clean rag or dry brush.
2. Inspect all wire connections especially at relays, terminal connections and circuit boards for tightness.
3. Inspect and check tightness of mounting bolts that mount washer frames to floor.

AFTER ANY SERVICE REINSTALL ALL PANELS AND SAFETY SCREENS BEFORE RECONNECTING POWER