

WASHER PREVENTIVE MAINTENANCE (PM) REQUIREMENTS MAKE SURE ALL POWER IS DISCONNECTED BEFORE MAKING CHECKS INSIDE MACHINE.

DAILY

- 1. Check that the door remains securely locked during the entire cycle.**
- 2. Clean the cabinet top around soap dispenser.**
- 3. Clean the soap dispenser and soap lid and check that all dispenser-mounting screws are in place and tight.**
- 4. Check the drain for leaking and proper draining.**
- 5. Check the water connections for leaks.**
- 6. Check door seal for foreign material.**
- 7. Leave the loading door open to aerate the washer when not in use.**

QUARTERLY

- 1. Check the drive belt for wear and proper tension.**
- 2. Clean lint and other foreign material from around drive motor.**
- 3. Remove water inlet hose filter screens and clean or replace as necessary.**
- 4. Check all electrical components for moisture and wipe away any foreign debris.**

ANNUALLY

- 1. Clean and remove lint and foreign debris from outside cover of VFD with a dry clean rag or dry brush.**
- 2. Inspect all wire connections especially at relays, terminal connections and circuit boards for tightness.**
- 3. Inspect and check tightness of mounting bolts that mount washer frames to floor.**

AFTER ANY SERVICE REINSTALL ALL PANELS AND SAFTEY SCREENS BEFORE RECONNECTING POWER