

STACK DRYER LINT BLOCKAGE OR CLOGGED SCREEN

Lint blockage or clogged screen

- Remove lint screen
- Remove lint from lint screen. Remove lint buildup in lint chamber using a shop vac.
- Clean and remove lint from burner assembly and recirculation duct. Access recirculation duct thru the burner housing assembly.







