Dexter Laundry Service Videos

Washer Programming & Service Videos

C-Series

- DexterLive C-Series USB Programming
- Price Programming C-Series Vended Washer
- **→ Door Lock Adjustment**
- -> Removal and Cleaning of the Pressure Switch Tube
- -> Cleaning and Replacing Drain Valve
- -> Cleaning and Servicing Water Inlet Valves
- → Installation of the Dexter Washer
- -> Coin Drop Removal and Cleaning
- -> F13 Troubleshooting

A-Series

- Price Programming for WCAD Vended Washer
- **→ Door Lock Adjustment**
- -> Removal and Cleaning of the Pressure Switch Tube
- -> Cleaning and Replacing Drain Valve
- -> Cleaning and Servicing Water Inlet Valves
- → Installation of the Dexter Washer
- -> Coin Drop Removal and Cleaning

V-Series / 6-Cycle

- -> Cycle Programming for WCVD OPL Washer
- **→** Door Lock Adjustment
- -> Removal and Cleaning of the Pressure Switch Tube
- → Cleaning and Replacing Drain Valve
- → Cleaning and Servicing Water Inlet Valves
- → Installation of the Dexter Washer
- -> Coin Drop Removal and Cleaning

N-Series

- **→** Door Lock Adjustment
- -> Removal and Cleaning of the Pressure Switch Tube
- → Cleaning and Replacing Drain Valve
- -> Cleaning and Servicing Water Inlet Valves
- → Installation of the Dexter Washer
- -> Coin Drop Removal and Cleaning

^{*}Please note: Displayed machine may vary in videos. Refer to the Service Manuals for more accurate representation.