

CHECKING AND REPLACING THE MAIN CONTROL PCB BOARD

Step 1 – Shut off power supply.

Step 2 – Remove top panel.

Step 3 – Check connections on PCB.

- Check all harness connections. Look for loose wires in the harness, and for corrosion or buildup on terminals.

Step 4 – Removing PCB board.

- Disconnect all wire harnesses from PCB.
- Loosen and remove (5) 5/16 nuts from mounting studs.
- Remove board from studs carefully not to lose the plastic spacers on the studs.
- Reinstall the PCB board in reverse order.
- **When tightening the (5) 5/16 nuts be sure to not over tighten**

